


#### Warning :















- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture **MUST BE ASSEMBLED BY TWO PEOPLE** on a soft surface such as a blanket or carpet.




30723

82" Dining Bench


#### Components and Hardware List

Top Bench	Cushion Seat	Leg (Left)	Leg (Right)	Center Leg	Short Stretcher	Long Stretcher
 (A) 1 pc.	 (B) 2 pcs.	 (C) 2 pcs.	 (D) 2 pcs.	 (E) 2 pcs.	 (F) 3 pcs.	 (G) 1 pc.
Allen Head Bolt M8-32 x 55mm  (H) 12 pcs.	Allen Head Bolt M6-32 x 35mm  (I) 3 pcs.	Lock Washer Ø9 x Ø13mm  (J) 15 pcs.	Flat Washer Ø8 x Ø20mm  (K) 15 pcs.	Allen Key 4 x 110mm  (L) 1 pc.	Wood Screw Ø4 x 50mm  (M) 6 pcs.	Tool Required (not provided) Phillips Screwdriver 


#### STEP 1: Do not fully tighten the bolts




### STEP 2:



### STEP 3: Using the Allen key to tighten all bolts



### STEP 4:



Bottom View