




Warning :

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.




37255 - Windsor Side Chair 2in


Components and Hardware List

<p>Chair Seat & Back (A)  1 pc.</p>	<p>Back Leg Left (B)  1 pc.</p>	<p>Back Leg Right (C)  1 pc.</p>	<p>Front Leg Left (D)  1 pc.</p>	<p>Front Leg Right (E)  1 pc.</p>		
<p>Side Stretcher Left (F)  1 pc.</p>	<p>Side Stretcher Right (G)  1 pc.</p>	<p>Center Stretcher (H)  1 pc.</p>	<p>Flat Washer 5/16" x 19*2mm (I)  8 pcs.</p>	<p>Spring Washer 5/16" (J)  8 pcs.</p>	<p>Allen Head Bolt 5/16"-18 x 2- 1/4" (K)  8 pcs.</p>	<p>5mm Allen Key (L)  1 pc.</p>
<p>Wood Screw #8 x 1" (M)  2 pcs.</p>	<p>Wood Screw #8 x 1-1/4" (N)  4 pcs.</p>	<p>Screw Driver not included </p>				


STEP 1: Do not fully tighten the bolts




STEP 2: Do not fully tighten the bolts



STEP 3: Do not fully tighten the Screws



STEP 4: Using the Allen key and a Phillips head screw driver, tighten all bolts, then tighten all screws.



Complete

