


Warning :

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.




42202
Round Cocktail Table


Components and Hardware List

<p>Glass Top</p> <p>(A) 1 pc.</p>	<p>Frame top</p> <p>(B) 1 pc.</p>	<p>Shelf</p> <p>(C) 1 pc.</p>	<p>Leg U</p> <p>(D) 1 pc.</p>	<p>Leg L</p> <p>(E) 2 pcs.</p>	<p>Allen Key M4</p> <p>(F) 1 pc.</p>	<p>Allen Head Bolt 1/4"-20 x 1-3/8"</p> <p>(G) 6 pcs.</p>
<p>Allen Head Bolt 1/4" X 20 X 5/8"</p> <p>(H) 4 pcs.</p>	<p>Spring Washer 1/4" x Ø12 x 1.5mm</p> <p>(I) 10 pcs.</p>	<p>Spring Washer 1/4" x Ø16 x 2mm</p> <p>(J) 6 pcs.</p>	<p>Flat Washer 1/4" x Ø16 x 2mm</p> <p>(K) 4 pcs.</p>	<p>Glass pad 12 x 3mm</p> <p>(L) 8 pcs.</p>		

Step 1:




Step 2: Do not fully tighten the bolts.




Attention: When attaching all legs to the shelf, use the carton from the packaging or a work surface to create a gap between the floor and the legs. This will allow the legs to easily be assembled and properly tightened.


Step 3: Using the Allen key to tighten all bolts.




Step 4: Attach glass pads



Step 5:



Step 6:



Adjustable Leveler