














Warning :

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture **MUST BE ASSEMBLED BY TWO PEOPLE** on a soft surface such as a blanket or carpet.


Components and Hardware List

 A 1 pc.	 B 2 pcs.	 C 2 pcs.	 D 2 pcs.	 E 1 pc.	 F 1 pc.	 G 2 pcs.	 H 12 pcs.	 I 12 pcs.	 J 12 pcs.	 K 1 pc.	 L 9 pcs.
---	--	--	--	--	---	--	---	---	--	---	--



79255
58" Uph Dining Bench 1 in


STEP 1: Do not fully tighten the bolts.




Screw Driver
not included




STEP 2: Do not fully tighten all Screws.




STEP 3: Do not fully tighten all Screws.



STEP 4 : Using the Allen key to tighten all bolts.



STEP 5: Use a Phillips head screwdriver to tighten all screws.



Complete

