















Warning :

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture **MUST BE ASSEMBLED BY TWO PEOPLE** on a soft surface such as a blanket or carpet.

Components and Hardware List

 <p>Seat Bench 1 pc.</p>	 <p>Side Leg (Right) 2 pcs.</p>	 <p>Side Leg (Left) 2 pcs.</p>	 <p>Middle Leg 2 pcs.</p>	 <p>Middle Stretcher 1 pc.</p>	 <p>79455 58" Uph Dining Bench 1in</p>	
 <p>Bottom Stretcher 1 pc.</p>	 <p>Side Stretcher 2 pcs.</p>	 <p>Allen Head Bolt Ø5/16"-18 x 2" 12 pcs.</p>	 <p>Spring Washer Ø5/16" x Ø13 12 pcs.</p>	 <p>Flat Washer Ø5/16" x Ø19 12 pcs.</p>	 <p>Allen Key 5mm 1 pc.</p>	 <p>Wood Screw #8 x 1-1/4" 9 pcs.</p>


STEP 1: Do not fully tighten the bolts.




Screw Driver
not included




STEP 2: Do not fully tighten all Screws.




STEP 3: Do not fully tighten all Screws.



STEP 4 : Using the Allen key to tighten all bolts.



STEP 5: Use a Phillips head screwdriver to tighten all screws.



Complete

